MOUNTING INSTRUCTIONS

6861 安 裝 說 明

- 1.) Use a unit of assembled accessory as template to locate appropriate drilling centers with pencil. 使用一組裝配完整的配件量測,並用鉛筆在預定鑽孔的位置,畫上記號.
- 2.) Disassemble Brackets away from the unit of accessory. 把固定基座從整組裝配的配件上拆卸下來.
- 3.) Use 6mm drilling bit to drill holes in your marked locations, when mounting on drywall, insert Plastic Anchors. 當安裝在水泥牆,使用1/4英时鑽頭,鑽孔深度4公分,崁入塑膠塞並使之齊平於牆面.
- 4.) Attach Bracket to wall with Wall Screws. 將固定基座以螺絲鎖在牆面上.
- 5.) Insert the Main Body into Brackets, and secure the Set Screws for installation. 在固定基座上面掛住產品本體,再用六角板手將埋頭螺絲鎖緊,完成安裝程序.



6861 SERIES:



巧時代 SHENG TAI BRASSWARE CO., LTD.